GAC

EPSA202610



EMPOW

Warranty Manual

Foreword

Thanks for choosing GAC !

We are sure that GAC will bring you greater driving pleasure. In order to keep your vehicle in good condition for a long t ime, please be sure to go to the GAC authorized shop for regular maintenance in accordance with "Regular Maintenan ce Schedule" in this manual, where quality service will be provided for you at a reasonable price, and the techni cal personnel who have received professional training from GAC International Co., Ltd.. (hereinafter referred to as " GAC ") will perform the maintenance according to the specific operation specification.

This manual is a certificate for the warranty and maintenance of your vehicle. Please enter the user information carefully in this manual and keep the manual properly. You are requested to present this manual when you accept the vehicle maintenance or apply for the vehicle warranty in the GAC authorized shop.

Best wishes for you: hope GAC can bring you pleasant driving experience!

GAC International Co., Ltd.

Table of Contents

Warranty Certificate 3

1. Vehicle handover 4

1.1 PDI 4

1.2 Vehicle handover 4

2. Warranty instructions 5

2.1 Warranty instructions 5

2.2 Responsibilities of vehicle owner 7

2.3 Obligations of GAC authorized shop 7

3. Maintenance instructions 8

3.1 Regular maintenance schedule 8

3.2 Supplementary maintenance under harsh driving conditions 11

3.3 Regular maintenance record 13

4. Ownership change 16

Warranty period

The warranty period refers to the period or mileage calculated from the date the dealer issues the purchase invoice.

Basic warranty period of EMPOW model: 72 months or 250,000 km (whichever comes first).

Basic warranty period of EMPOW commercial vehicles: 12 months or 100,000 km (whichever comes first).

Warranty Terms on Wearing Parts, Lubricating Oil and Operating Fluid.

- When the wearing parts which are initially malfunctioned parts and the malfunction are resulted from the defects of the materials or made during manufacture. The wearing parts and warranty period are set forth below:

Wearing Parts	Warranty Period
Air Filter Cartridge, Oil Filter, Fuel Filter, Air-Conditioner Filter, Bulb, Spark Plug, Fuse, and Tire.	3 months or 5,000 km, whichever comes first
Driving Belt, Friction Plate, Cutch Disc, Windshield Wiper, Brake Disc	6 months or 5,000 km, whichever comes first
Battery of Remote Control	6 months or 10,000 km, whichever comes first
Rechargeable Battery	12 months or 20,000 km, whichever comes first

- Lubricating Oil, Operating Fluid etc. Lubricating oil or operating oil such as engine oil, transmission gear oil, differential gear oil, steering gear oil, power steering fluid, automatic transmission fluid, brake fluid, clutch fluid, shock absorber fluid, cleaning fluid, lubricating lipid, coolant, battery electrolyte and refrigerant are not covered by the warranty.
- Followed by warranty repair, all parts and oil or fluid listed above which are needed or required to be replaced can be considered as part of the warranted items.

Warranty Certificate

User Profile

Owner name:

Owner's attribute: Profession

Tel.:

Address:

Postcode:

Purchase date:
(DD/MM/YYYY)

Signature of vehicle owner:

(DD/MM/YYYY)

Vehicle Information

Vehicle model:

VIN:

Engine serial number:

License plate number:

Name of authorized shop conducting first maintenance:
(Seal)

(DD/MM/YYYY)

Name of authorized shop:
(Seal)

(DD/MM/YYYY)

Warranty copy: reserved by the owner

1. Vehicle handover

1.1 PDI

The vehicle indicated in the Warranty Certificate attached in this manual has been subjected to PDI in accordance with the provisions specified by GAC International Co., Ltd. Please ask for the PDI checklist from the authorized shop for specific inspection items.

Inspection date:

_____

Inspector:

_____

Seal of authorized shop:

1.2 Vehicle handover

Before delivery, the GAC authorized shop will inspect and clean the vehicle completely and submit the PDI checklist to you for your confirmation and signature. If you are unsatisfied with the condition of the delivered vehicle, please inform the GAC authorized shop and ask for re-adjustment.

Please be sure to check whether the Warranty Certificate is provided when you accept the vehicle; if not, the free first maintenance service and warranty services will be invalidated.

Followings are to be handed over with vehicle (e.g.: ☑Yes ☒No)	
☐ *Owner's Manual* (QR code) ☐ *Warranty Manual* ☐ *Driving Guide* (QR code) ☐ *Navigation Manual* (Optional) ☐ Certificate of conformity ☐ First key ☐ Second key	☐ Spare tire (optional) ☐ Inflator pump + tire sealer (optional) ☐ Warning triangle ☐ Reflective vest ☐ Driver's tools (refer to the Owner's Manual) ☐ Completed PDI checklist
It is hereby confirmed that I have checked the items listed above and accepted the purchased vehicle.	
Signature of vehicle owner/ authorized person:	
*Please pay attention to checking, if any, the operation instructions provided for your vehicle.	

2. Warranty instructions

2.1 Warranty instructions

Warranty object

Vehicles manufactured by GAC International Co., Ltd., and sold and serviced by the GAC authorized shop.

CAUTION

If you do not fill in the warranty copy and make the warranty registration, we have the right to refuse to provide warranty services for you.

The warranty services are provided to the owner of a new vehicle (if the vehicle owner changes within the warranty period, the warranty is still valid).

Warranty period

The warranty period refers to the period or mileage calculated from the date the dealer issues the purchase invoice.

Basic warranty period of EMPOW model: 72 months or 250,000 km (whichever comes first).

Basic warranty period of EMPOW commercial vehicles: 12 months or 100,000 km (whichever comes first）.

Warranty coverage

The warranty liability of GAC is to repair products, including:

1. Repair or replacement of parts being considered defective by GAC .
2. Repair of paint on vehicle body being considered defective by GAC .
3. Man-hour cost for the above repair.

Warranty terms

1. When verifying the warranty items, the GAC authorized shop will consider the following conditions that are outside the warranty coverage of the GAC :

a) Use of a vehicle in a country or region other than that where the vehicle is sold.

b） Vehicle damage caused by the maintenance, repair and adjustment performed in places other than the GAC authorized shop.

c） Vehicle defects caused by use of parts, lubricating grease and liquids other than genuine ones specified by GAC.

d） Vehicle damage caused by negligence, improper handling and the driving methods other than those specified in the Owner's Manual or the operation outside the limit operating range (such as maximum load and seating capacity) of the vehicle.

e） Vehicle damage caused by application of corrosive or low-quality cleaning agent.

f) Modification, addition, adjustment and removal of the vehicle prohibited in the Owner's Manual without the approval of GAC .

g) Vehicle damage caused by abnormal use, improper handling, negligence or the operation performed by the unqualified or unskilled driver and the application for races (such as vehicle race or rally).

h) Sensation problems that do not affect the vehicle performance.
   - The warranty of GAC does not cover the defective sensation problems that do not affect the quality, function or performance of products.

i) Any damage caused by improper storage or transportation.

j) Vehicle defects caused by the natural disaster, fire, traffic accident, theft and the secondary damage incurred.

k) Vehicle damage caused by the environmental conditions other than the normal operation conditions of household automobiles (such as air pollution, chemical compound, guano, sea salt or other corrosive substances).

l) Vehicle corrosion or fault caused by the water immersion.

m) Vehicle surface corrosion caused by the flying stone or external scratch.

2. The warranty does not cover the maintenance items, fluids and auxiliary materials that are not necessary for the warranty and maintenance.
3. The warranty does not cover the following incidental charges.
   For example:
   - Expenses for communication, mediation, meal and accommodation because of a fault.
   - Any relevant personal injury or property damage.
4. The GAC reserves the right to determine the repair methods and warranty coverage.
5. All parts under the warranty coverage are the property of GAC .
6. The fuel, lubricating grease and fluids specified by GAC shall be used.

CAUTION

To avoid the dispute over the warranty liability, please note that:

- **The dispute over the warranty liability may arise if the vehicle is not subject to regular maintenance and inspection at a GAC authorized shop according to the Owner's Manual and the Warranty Manual.**
- **The dispute over the warranty liability may arise if the user changes the original state of fault deliberately after the fault occurs so that the fault cannot be identified or the user has fraudulent behavior.**

2.2 Responsibilities of vehicle owner

1. Subject your vehicle to first maintenance at a GAC authorized shop within 5,000km or 3 months (whichever comes first).
2. Make sure that your vehicle is maintained and inspected at the GAC authorized shop according to the regular maintenance schedule in this manual.
3. Get any fault of your vehicle inspected and repaired at the GAC authorized shop in time, which may be covered under the warranty.

CAUTION

- **The dispute over the warranty liability may arise if the vehicle is sent to any places other than the GAC authorized shop formaintenance and repair.**
- **The vehicle that has not received first maintenance (referring to the maintenance within 5,000km or 3 months (whichever comes first)) will be rejected for free first maintenance.**

Please bring this manual with you when you go to the GAC authorized shop.

2.3 Obligations of GAC authorized shop

Fill in the Warranty Certificate contained in this manual and explain the warranty procedures of GAC vehicle when delivering a new vehicle to the user.

Explain the importance of regular maintenance fully to the user.

Ensure that any maintenance and repair can be completed according to the standard specified by GAC, whether they are covered under the warranty or not.

For the damage or defects under the warranty coverage, the authorized shop should provide necessary vehicle repair or treatment to the user.

3. Maintenance instructions

3.1 Regular maintenance schedule

The maintenance cycle in the following maintenance schedule is based on normal driving conditions and environments. In harsh operating conditions or environments, the vehicle shall be maintained at an interval of 5000 km or 3 months.

Perform the maintenance according to the specified mileage or time interval (whichever comes first)	km x 1000	20	40	60	80	100	120	140	160	180	200
	Months	12	24	36	48	60	72	84	96	108	120
★ Change the engine oil		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Replace the engine oil filter		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the spark plug		Exemption									
Replace the spark plug*1		Every 60,000km									
Check the V-ribbed belt		Every 20,000km or 12 months									
Replace the V-ribbed belt		Every 60,000km or 36 months									
Replace the fuel filter		Every 40,000km or 24 months									
Replace the canister filter		Every 60,000km or 36 months									
Add the fuel system cleaning agent		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Clean the electronic throttle		Every 20,000km									
Check and clean the air cleaner element		First and second times at 5,000km or 3 months, and inspection free thereafter									
Clean the air cleaner cover and replace the air cleaner element		Every 20,000km or 12 months									
Check the cooling system for leakage and add the coolant when necessary		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
★ Change the engine coolant		Every 40,000km or 24 months									
★ Change the intercooler system coolant		Every 40,000km or 24 months									
Check the transmission fluid (7WDCT)		Exemption									
Change the transmission fluid (7WDCT)		First at 50,000km or 36 months, and thereafter every 60,000km or 36 months									
Replace the press filter element (7WDCT)		First at 5,000km or 3 months, second at 50,000km or 36 months, and thereafter every 60,000km or 36 months									

Perform the maintenance according to the specified mileage or time interval (whichever comes first)	km x 1000	20	40	60	80	100	120	140	160	180	200
	Months	12	24	36	48	60	72	84	96	108	120
Check the exhaust (only for leakage; the exhaust compositions are to be inspected during the annual inspection)		Every 10,000km or 6 months									
★ Change the brake fluid		Every 40,000km or 24 months									
Check the parking brake and the brake pedal (check the function and free travel of the pedal and parking brake)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the brake disc and brake lining (check their thickness and wear pattern, and replace them when necessary)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Inspect the wheel fixing bolt (check and tighten the bolt to the specified torque)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the wear pattern of the tire/ hub (including the spare tire), carry out tire rotation and correct the tire pressure when necessary		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the chassis bolts (check and tighten the bolts to the specified torque)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the brake system (check the brake fluid pipes for leakage and check the brake fluid level and add the brake fluid when necessary)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the steering tie rod (check the clearance and check whether the connection is firm)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the underbody (check the fuel pipe, brake fluid pipe and underbody protective layer for damage, and the exhaust pipe for leakage and looseness)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Replace the fuel hose		Every 96 months (or when any crack is found)									
Check the suspension ball joint and dust cover (check for loose ball joint or leaky dust cover)		•	•	•	•	•	•	•	•	•	•
Check the suspension assembly (check that the bush is free from aging and breakage, the connecting bolt and nut are tightened to specified torque and the linkage is free from deformation and cracks)		•	•	•	•	•	•	•	•	•	•

Perform the maintenance according to the specified mileage or time interval (whichever comes first)	km x 1000	20	40	60	80	100	120	140	160	180	200
	Months	12	24	36	48	60	72	84	96	108	120
Check the wiper/washer (add the washer fluid and check the function of wiper/washer, adjust the nozzle when necessary)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check whether there are leaves or other debris on the surface of the wiper cover		Every 10,000km or 6 months									
Check the door check, dowel pin, door lock, hood/ trunk lid hinge and latch (check their functions and clean the dust on the door check and lubricate the check)		Every 10,000km or 6 months									
Check the interior and exterior lamps and electrical consumers of the vehicle body		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Read OBD in-use monitoring data		Synchronized with vehicle maintenance									
Self-diagnosis (check the fault message with the professional diagnostic scan tool)		Synchronized with vehicle maintenance									
Check the battery (check the battery condition with the special tool, check whether the connection between the positive and negative poles of battery is firm, and check the battery voltage)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									
Check the headlamp (check the lamplight and adjust it when necessary)		Every 10,000km or 6 months									
Check the A/C filter element		Every 10,000km or 6 months									
Replace the A/C filter element		●	●	●	●	●	●	●	●	●	●
Test run (performance inspection)		Each time maintenance is done									
Visually check the following items											
Dust cover of transmission drive shaft (check for leakage or damage)		First and second times at 5,000km or 3 months, and thereafter every 10,000km or 6 months									

★ : Be sure to check the levels (of engine oil, coolant and brake fluid) before driving.

*1: If there is impurity in the gasoline used, please replace the spark plug frequently. If the engine idle speed is unstable, the spark plug should be replaced immediately.

3.2 Supplementary maintenance under harsh driving conditions

The maintenance cycle is determined based on the normal driving conditions, therefore the maintenance frequency for certain maintenance items should be increased or the maintenance cycle should be shortened if the vehicle is used in harsh conditions.

Harsh conditions include the followings:

1. The vehicle often runs for a short trip
2. The engine is kept running at an idle speed continuously and the vehicle runs intermittently (for example: the vehicle is used as a taxi).
3. The vehicle runs in a muddy, dusty area or environment.
4. The vehicle is used to tow another vehicle frequently or to load the luggage on the roof rack during running, or the vehicle runs on a mountain road.
5. The vehicle runs for a long time in extreme cold (below freezing point) or hot (above 35°C) climates
6. The vehicle runs more than 20,000km every year or runs at high speed frequently.
7. The vehicle runs for a long distance at a low speed.

Item	Harsh conditions	Maintenance requirements
Change the engine oil and replace the oil filter	1,2,3,5,7	2,500km or 3 months
Change the engine coolant	3,5,6	40,000km
Check the wheel fixing bolt	1,2,3,4,5,6	5,000km or 3 months

Item	Harsh conditions	Maintenance requirements
Check the chassis bolts (check and tighten the bolts to the specified torque)	1,2,3,4,5,6	10,000km or 6 months
Check the steering tie rod (check the clearance and check whether the connection is firm)	1,2,3,4,5,6,7	First at 5,000 km or 3 months, and thereafter every 10,000 km or 6 months
Check the suspension ball joint and dust cover (check for loose ball joint or leaky dust cover)	1,2,3,4,5,6	10,000km or 6 months
Check the suspension assembly (check that the bush is free from aging and breakage, the connecting bolt and nut are tightened to specified torque and the linkage is free from deformation and cracks)	1,2,3,4,5,6	10,000km or 6 months
Replace the A/C filter element	3,5	10,000km or 12 months

Note

The maintenance frequency of air cleaner and V-ribbed belt shall be increased when the vehicle is used under harsh conditions.

3.3 Regular maintenance record

5,000km or 3 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	10,000km or 6 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	20,000km or 12 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	30,000km or 18 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)
40,000 km or 24 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	50,000 km or 30 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	60,000 km or 36 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	70,000km or 42 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)
80,000km or 48 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	90,000km or 54 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	100,000km or 60 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	110,000km or 66 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)

120,000km or 72 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	130,000km or 78 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	140,000km or 84 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	150,000km or 90 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)
160,000km or 96 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	170,000km or 102 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	180,000km or 108 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	190,000km or 114 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)
200,000km or 120 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	210,000km or 126 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	220,000km or 132 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	230,000km or 138 months Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)

240,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	250,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	260,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	270,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)
280,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	290,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	300,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	310,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)
320,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	330,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	340,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)	350,000km Mileage:_____ Date:_____(DD/MM/YYYY) Authorized shop:_____ (Seal)

4. Ownership change

Ownership Change Record	
User Profile	Vehicle Information
Owner name:	Vehicle model:
Owner's attribute: Male/female Profession:	VIN:
Address:	Engine serial number:
Postcode:	Transmission number:
Tel.:	Body color:
Contact person:	Interior trim color:
Address:	Key number:
Postcode:	When the original registration content in the warranty certificate changes, the GAC Motor authorized shop must fill in the change record and report it to the GAC .
Tel.:	
Date of change: (DD/MM/YYYY)	
□Owner change □Address change □Reissue Signature of owner:	Name of authorized shop (seal): Person in charge (signature):
(DD/MM/YYYY)	(DD/MM/YYYY)



GAC INTERNATIONAL CO.,LTD.
Address: No. 60 Donglong Road, Panyu District, Guangzhou, P.R. China
Postcode: 511434
Customer service hotline: 400-158-9999



شركة جي أيه سي الدولية المحدودة

العنوان: الرقم 60 في طريق دونغلونغ في حي بانيو في مدينة قوانغتشو في جمهورية الصين الشعبية
الرمز البريدي: 511434
الخط الساخن للخدمة: 400-158-9999

4. تغيير المستخدم

جدول تسجيل تغيير المستخدم	
معلومات المستخدم	معلومات السيارة
اسم مالك السيارة:	طراز السيارة:
سمة المالك: ذكر / أنثى المهنة:	رقم الإطار:
عنوان تفصيلي:	رقم المحرك:
الرمز البريدي:	رقم علبة السرعة:
رقم الهاتف:	لون السيارة:
جهات الاتصال:	لون داخل الزخرفة:
عنوان تفصيلي:	رقم المفتاح:
الرمز البريدي:	عندما تغيير الضمان الأصلي، يجب لشركة جي أيه سي للسيارات ملء سجل التغيير وإبلاغ شركة جي أيه سي الدولية المحدودة.
رقم الهاتف:	
تاريخ التغيير: سنة شهر يوم	
☐تغيير المستخدم ☐ تغيير العنوان ☐ إعادة الإصدار	
توقيع المستخدم:	اسم المحل الخاص (الختم):
	الشخص المسؤول (التوقيع):
سنة شهر يوم	سنة شهر يوم

240,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

250,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

260,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

270,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

280,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

290,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

300,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

310,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

320,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

330,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

340,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

350,000 كم

عدد الأميال:_____

التاريخ: سنة_____شهر__ يوم_

المتجر الخاص:_____

(ختم)

120,000 كيلومتر أو 72 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	130,000 كيلومتر أو 78 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	140,000 كيلومتر أو 84 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	150,000 كيلومتر أو 90 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)
160,000 كيلومتر أو 96 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	170,000 كيلومتر أو 102 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	180,000 كيلومتر أو 108 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	190,000 كيلومتر أو 114 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)
200,000 كيلومتر أو 120 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	210,000 كيلومتر أو 126 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	220,000 كيلومتر أو 132 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)	230,000 كيلومتر أو 138 شهرًا عدد الأميال:_____ التاريخ: سنة_____شهر___ يوم_ المتجر الخاص:_____ (ختم)

3.3 جدول تسجيل الصيانة الدورية

5000 كيلومتر أو 3 أشهر	10,000 كيلومتر أو 6 أشهر	20,000 كيلومتر أو 12 أشهر	30,000 كيلومتر أو 18 أشهر
عدد الأميال:_____	عدد الأميال:_____	عدد الأميال:_____	عدد الأميال:_____
التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_
المتجر الخاص:_____	المتجر الخاص:_____	المتجر الخاص:_____	المتجر الخاص:_____
(ختم)	(ختم)	(ختم)	(ختم)

40,000 كيلومتر أو 24 شهرًا	50,000 كيلومتر أو 30 شهرًا	60,000 كيلومتر أو 36 شهرًا	70,000 كيلومتر أو 42 شهرًا
عدد الأميال:_____	عدد الأميال:_____	عدد الأميال:_____	عدد الأميال:_____
التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_
المتجر الخاص:_____	المتجر الخاص:_____	المتجر الخاص:_____	المتجر الخاص:_____
(ختم)	(ختم)	(ختم)	(ختم)

80,000 كيلومتر أو 48 شهرًا	90,000 كيلومتر أو 54 شهرًا	100,000 كيلومتر أو 60 شهرًا	110,000 كيلومتر أو 66 شهرًا
عدد الأميال:_____	عدد الأميال:_____	عدد الأميال:_____	عدد الأميال:_____
التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_	التاريخ: سنة_____شهر__ يوم_
المتجر الخاص:_____	المتجر الخاص:_____	المتجر الخاص:_____	المتجر الخاص:_____
(ختم)	(ختم)	(ختم)	(ختم)

مشروع	شروط سينة	طلب الصيانة
فحص مسامير الهيكل (فحص وشد حسب اللوائح)	1, 2, 3, 4, 5, 6	10,000 كيلومتر أو 6 أشهر
تحقق من قضيب ربط التوجيه (افحص الخلوص، وقم بالتحقق مما إذا كان الاتصال ثابتًا) (افحص الخلوص، وقم بالتحقق مما إذا كان الاتصال ثابتًا)	1, 2, 3, 4, 5, 6, 7	أول 5000 كيلومتر أو 3 أشهر، ثم كل 10000 كيلومتر أو 6 أشهر
فحص وصلة كرة التعليق وغطاء الغبار (فحص عدم فضفاض رأس كروي، لا تسرب للزيت في غطاء الغبار)	1, 2, 3, 4, 5, 6	10,000 كيلومتر أو 6 أشهر
فحص مكونات التعليق (فحص الجلبة دون الشيخوخة، التلف، عزم ربط مسامير وصواميل، والقضيب بدون تشوه أو تشقق)	1, 2, 3, 4, 5, 6	10,000 كيلومتر أو 6 أشهر
تغيير نواة فلتر مكيف الهواء	3, 5	10.000 كيلومتر أو 12 أشهر

ملاحظة:

عند استخدام السيارة في ظروف قاسية، يجب زيادة وتيرة صيانة فلتر الهواء و الحزام المضلع على شكل حرف V.

3.2 الصيانة التكميلية في ظروف السياق السيئة

تعتمد دورة الصيانة على شروط السياق العادية، إذا كان استخدام السيارة في واحد أو كثير من الشروط المعاكسة يجب أن يزيد من عدد عناصر الصيانة، أو يقصر دورة الصيانة.

الحالات التالية هي شروط سيئة:

1. تقود السيارة بالرحلات القصيرة بشكل متكرر.
2. تباطؤ المحرك المستمر أو القيادة المتقطعة (مثل سيارات الأجرة).
3. القيادة في مناطق أو بيئات موحلة أو مغبرة
4. جر المقطورة بشكل متكرر أو تحمل أمتعة على الرف العلوي، أو القيادة على الطرق الجبلية.
5. القيادة في ظروف مناخية باردة (أقل من درجة التجمد) أو درجة الحرارة المرتفعة (أكبر من 35 درجة مئوية) لفترة طويلة
6. القيادة لأكثر من 20,000 كيلومتر كل عام، أو القيادة بسرعة عالية بشكل متكرر وما إلى ذلك.
7. القيادة لمسافات طويلة بسرعة منخفضة.

مشروع	شروط سيئة	طلب الصيانة
استبدال زيت المحرك وفلتر الزيت	1, 2, 3, 5, 7	2,500 كيلومتر أو 3 أشهر
تغيير سائل التبريد للمحرك	3, 5, 6	40,000 كيلومتر
فحص برغي تثبيت العجلة	1, 2, 3, 4, 5, 6	5000 كيلومتر أو 3 أشهر

إجراء الصيانة وفقا لأميال السياق أو الفترة المحددة (أيهما يأتي أولاً يسود)	كم × 1000	20	40	60	80	100	120	140	160	180	200
	عدد الشهر	12	24	36	48	60	72	84	96	108	120
افحص الماسحة / الغسالة (املأ سائل الغسيل ، وفحص الوظيفة، واضبط الفوهات إذا لزم الأمر)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
قم بالتحقق مما إذا كانت هناك أوراق شجر وغيرها من الحطام على سطح غطاء الممسحة	كل 10000 كيلومتر أو 6 أشهر بعد ذلك										
افحص سدادات الباب/ دبوس التثبيت وأقفال الأبواب ومفصلات غطاء المحرك / غطاء صندوق السيارة الخلفي والمشابك (افحص الوظيفة، يجب تنظيف وتزييت السدادات)	كل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص أجهزة الإنارة داخل وخارج السيارة والمعدات الكهربائية	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
OBD القراءة مع بيانات المراقبة الحالية	تزامن مع صيانة أو إصلاح السيارة										
التشخيص الذاتي (الاستعلام عن معلومات خطأ مع معدات التشخيص المهنية)	تزامن مع صيانة أو إصلاح السيارة										
افحص البطارية (قم بالتحقق من حالة البطارية باستخدم أدوات خاصة، وقم بالتحقق مما إذا كانت التوصيلات الموجبة والسالبة ثابتة، وافحص الجهد الكهربائي)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص المصابيح الأمامية (فحص الضوء وتعديله عند الضرورة)	كل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص نواة فلتر مكيف الهواء	كل 10000 كيلومتر أو 6 أشهر بعد ذلك										
تغيير نواة فلتر مكيف الهواء		•	•	•	•	•	•	•	•	•	•
اختبار القيادة (فحص الأداء)	بعد كل صيانة										
فحص العناصر التالية بصريًا											
سترة الغبار رمح الحركة (سواء تسرب أو تلف)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										

★: يجب فحص كمية زيت المحرك والمبرد وسائل التبريد بعناية قبل كل قيادة.

*1: إذا كان البنزين الذي تستخدمه يحتوي على شوائب، فيجب استبدال شمعات الإشعال بشكل متكرر. إذا تبين أن سرعة تباطؤ المحرك غير مستقرة، فيجب استبدال شمعات الإشعال على الفور.

إجراء الصيانة وفقا لأميال السياق أو الفترة المحددة (أيهما يأتي أولاً يسود)	كم × 1000	20	40	60	80	100	120	140	160	180	200
	عدد الشهر	12	24	36	48	60	72	84	96	108	120
قم بالتحقق من انبعاثات العادم (قم بالتحقق فقط من تسرب الهواء، ويقوم بفحص العادم عند الفحص السنوي للسيارة)	كل 10000 كيلومتر أو 6 أشهر										
★ استبدال سائل الفرامل	استبدلها كل 40000 كيلومتر أو 24 شهرًا										
تحقق فرامل التوقف، دواسة الفرامل (تحقق وظيفة دواسة الفرامل وفرامل التوقف، رحلة مجانية)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
قرص الفرامل ودواسات الفرامل (تحقق حالة السمك والتآكل وتغييره عند الضرورة)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص برغي تثبيت العجلة (فحص وشد عزم الدوران حسب اللوائح)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص حالة تآكل الإطار/المحور (يشمل الإطار الاحتياطي) والضغط، يتم استبدال الإطار عند الضرورة، ضبط ضغط الإطارات في نفس الوقت	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص مسامير الهيكل (فحص وشد حسب اللوائح)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص نظام الفرامل (تحقق سواء تسرب خط أنابيب زيت الفرامل، تحقق مستوى زيت الفرامل وتجديده عند الضرورة)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
فحص قضيب ربط التوجيه (فحص الفجوة وتحقق سواء الاتصال ثابت)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
تحقق السيارة السفلي (تحقق سواء تالفة أنبوب الوقود، أنبوب سائل الفرامل والطبقة الواقية السفلية، سواء تسرب أنبوب العادم وسواء التثبيت موثوقًا)	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 10000 كيلومتر أو 6 أشهر بعد ذلك										
استبدل خرطوم الوقود	استبدله كل 96 شهرًا أو قبل ذلك إذا تم العثور على تشقق عليه										
تحقق من الوصلة الكروية لنظام التعليق والغطاء الواقي من الغبار (لا توجد وصلات كروية مفكوكة، ولا يوجد تسرب للزيت من الغطاء الواقي من الغبار)		•	•	•	•	•	•	•	•	•	•
فحص مكونات التعليق (فحص الجلبة دون الشيخوخة، التلف، عزم ربط مسامير وصواميل، والقضيب بدون تشوه أو تشقق)		•	•	•	•	•	•	•	•	•	•

3. تعليمات العناية

3.1 جدول الصيانة الدورية

من الضرورة، اتبع خطوات الإضافة، التنظيف، الغسل، الضبط، التشحيم، الإصلاح أو الاستبدال بعد الفحص.

إجراء الصيانة وفقا لأميال السياق أو الفترة المحددة (أيهما يأتي أولاً يسود)	كم × 1000	20	40	60	80	100	120	140	160	180	200
	عدد الشهر	12	24	36	48	60	72	84	96	108	120
★ تغيير زيت المحرك	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 6 أشهر أو 10000 كيلومتر لاحقا										
تغيير فلتر زيت المحرك وفلتر الزيت	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 6 أشهر أو 10000 كيلومتر لاحقا										
فحص قابس الإشعال	خالي من الفحص										
تغيير قابس الإشعال *1	استبدلها كل 60.000 كيلومتر										
فحص وجود أسافين متعددة	كل 20.000 كيلومتر أو 12 أشهر										
تغيير وجود أسافين متعددة	استبدلها كل 60.000 كيلومتر أو 36 شهرًا										
تغيير فلتر الوقود	كل 40.000 كيلومتر أو 24 أشهر										
استبدل فلتر خزان الكربون	كل 60.000 كيلومتر أو 36 أشهر										
إضافة منظف نظام الوقود	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 6 أشهر أو 10000 كيلومتر لاحقا										
تنظيف الخانق الإلكتروني	تنظيف كل 20000 كم										
فحص وتنظيف عنصر فلتر الهواء	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، يتم الاعفاء من عمليات الفحص اللاحقة										
تغطية نواة فلتر مكيف الهواء، تغيير نواة فلتر مكيف الهواء	استبدلها كل 20.000 كيلومتر أو 12 شهرًا										
تحقق سواء وجود تسربات في نظام التبريد وتجديد سائل التبريد عند الضرورة	كل 3 أشهر أو 5000 كيلومتر في أول 2 مرتين، وكل 6 أشهر أو 10000 كيلومتر لاحقا										
★ تغيير سائل التبريد للمحرك	استبدلها كل 40000 كيلومتر أو 24 شهرًا										
★ استبدل المبرد في نظام المبرد البيني	استبدلها كل 40000 كيلومتر أو 24 شهرًا										
فحص زيت ناقل الحركة (7WDCT)	خالي من الفحص										
تغيير زيوت التشحيم لناقل الحركة تلقائيا (7WDCT)	50.000 كيلومتر أو 36 أشهر في أول المرة، وكل 60.000 كيلومتر أو 36 أشهر بعد ذلك										
استبدل عنصر الفلتر (7 WDCT)	لمرة أول 5,000 كيلومتر أو 3 أشهر، ومرة ثانية 50000 كيلومتر أو 36 شهرًا، ثم كل 60000 كيلومتر أو 36 شهرًا										

2.2 مسؤولية مالك السيارة

1. إذا كانت المسافة المقطوعة بالسيارة 5000 كيلومتر أو في غضون 3 أشهر (أيهما يأتي أولاً)، يرجى الذهاب إلى المتجر الخاص بشركة جي إيه سي لإجراء الصيانة الأولى.
2. قم بالتأكد من صيانة وفحص سيارتكم في المتجر الخاص بشركة جي إيه سي وفقًا لجدول الصيانة المنتظمة في هذا الدليل.
3. انتقل على الفور إلى المتجر الخاص بشركة جي إيه سي لإصلاح أي فشل متعلقة بسيارتكم، بحيث قد يغطيه الضمان.

ملاحظة

- قد تخضع السيارة التي يتم صيانتها وإصلاحها خارج أي متجر خاص بشركة جي إيه سي لنزاعات الضمانات الثلاثة.
- ستفقد السيارة التي لم تتم صيانتها لأول مرة (5000 كيلومتر أو صيانة في غضون 3 أشهر، أيهما أولاً) الحق في الاستمتاع بالصيانة الأولى المجانية.

يرجى ذهب إلى شركة جي أيه سي للسيارات مع إحضار هذا الدليل.

2.3 واجب شركة جي أيه سي للسيارات

عندما تسليم السيارة الجديدة إلى العميل، أكمل بنود الضمان في هذا الدليل وشرح له إجراءات الضمان الخاصة بشركة جي أيه سي للسيارات.

شرح للمستخدم أهمية الصيانة الدورية للسيارة.

يتم ضمان إجراء أي صيانة وإصلاح، سواء بموجب الضمان وفقًا لمعايير جي أيه سي للسيارات.

بالنسبة للأضرار أو العيوب التي يغطيها الضمان، يجب تزويد المستخدم بالإصلاح أو المعالجة اللازمة.

f) التعديلات والإضافات وتفكيك السيارة المحظورة في دليل المستخدم دون إذن من شركة جي إيه سي.

g) تلف السيارة الناتج عن الاستخدام غير الطبيعي وسوء المعالجة والإهمال والتشغيل من قبل سائقين غير مؤهلين أو غير مهرة واستخدام السيارة للمنافسة (مثل السباق أو الرالي، إلخ).

h) المشكلة الإدراكية التي لا تؤثر على الأداء.

- لن تقدم شركة جي إيه سي ضمانًا للشعور السيئ الذي لا يؤثر على جودة المنتج أو وظيفته أو أدائه.

i) أي ضرر ناتج عن سوء التخزين أو النقل.

j) العيوب الناتجة عن الكوارث الطبيعية والحرائق وحوادث المرور والسرقة والأضرار الثانوية الناتجة عن هذه الكوارث.

k) الضرر الناجم عن الظروف البيئية خارج الاستخدام العادي للسيارات المنزلية، مثل تلوث الهواء الصناعي أو المركبات الكيميائية أو فضلات الطيور أو ملح البحر أو المواد المسببة للتآكل الأخرى.

l) التآكل والفشل الناجم عن الغمر في الماء.

m) تآكل السطح الناجم عن الحجارة المتطايرة أو التآكل الخارجي.

2. لا يشمل الضمان عناصر الصيانة مثل الزيت، الفلتر بدون ضمان والزيوت ومواد المساعدة.

3. لا يشمل الضمان النفقات الإضافية التالية.

مثل:

- نفقات الاتصالات والوساطة والوجبات والإقامة وما إلى ذلك بسبب الفشل.
- أي إصابة شخصية أو تلف في الممتلكات ذو الصلة.

4. تحتفظ جي أيه سي للسيارات بالحق في تحديد طريقة الإصلاح ونطاق الضمان.

5. جميع الأجزاء والمكونات التي تم استبدالها في نطاق الضمان هي مملوكة لشركة جي إيه سي.

6. استخدم الوقود، شحم التزليق والمواد السائلة المحددة بواسطة جي أيه سي للسيارات.

ملاحظة

من أجل تجنب الخلافات حول مسؤولية الضمانات الثلاث، يرجى ملاحظة:

- اذا السيارة لا تعود بانتظام إلى المتجر الخاص بشركة جي إيه سي للفحص والاصلاح والفحص وفقًا للمتطلبات ذات الصلة من "دليل المستخدم" و "دليل الضمان"، قد يتسبب في نزاع حول مسؤولية الضمانات الثلاثة.
- بعد تعطل السيارة، اذا يدمر المستخدم عمدًا الحالة الأصلية للفشل، مما يتسبب في فشل غير محدد أو سلوك مخادع، قد يتسبب في نزاع حول مسؤولية الضمانات الثلاثة.

2. تعليمات الضمان

2.1 تعليمات الضمان

كائن الضمان

المركبات التي تنتجها شركة جي أيه سي للمركبات ويتم بيعها وصيانتها من قبل متاجرها المعينة.

ملاحظة

ستفقد السيارة حقوق الضمان عدم ملء جدول الضمان وتسجيل الضمان.

يتم تقديم الضمان لمالك السيارة الجديدة (إذا تغير المالك خلال فترة الضمان، يظل الضمان ساري المفعول).

فترة الضمان

تشير فترة الضمان إلى الفترة أو أميال السياق المحسوبة من تاريخ إصدار البائع لفاتورة الشراء.

فترة الضمان الأساسية لطراز EMPOW: 72 شهرًا أو 250,000 كيلومتر (أيهما يأتي أولاً).

فترة الضمان الأساسية للمركبة التجارية لطراز EMPOW: 12 شهرًا أو 100,000 كيلومتر (أيهما يأتي أولاً).

نطاق الضمان

مسئولية ضمان جي أيه سي للسيارات هو إصلاح المنتجات، بما في ذلك:

1. قم بإصلاح أو استبدال الأجزاء المعيبة في رأي شركة جي إيه سي.
2. قم بإصلاح عيوب طلاء الجسم في رأي شركة جي إيه سي.
3. تكلفة الساعة المقابلة للإصلاح أعلاه المطلوبة.

شروط الضمان

1. ستراعي شركة جي أيه سي للسيارات العوامل التالية عند تحديد الضمان، النقاط التالية غير مشمول بضمان جي أيه سي للسيارات:

a) تُستخدم السيارة في بلدان وأماكن أخرى غير بلد البيع.

b) الضرر الناجم عن الصيانة والإصلاح والتصحيح خارج المتجر الخاص بشركة جي إيه سي.

c) العيوب الناتجة عن عدم استخدام قطع غيار أصلية وشحوم التشحيم والمواد السائلة المحددة من قبل شركة جي إيه سي.

d) تلف السيارة الناتج عن الإهمال أو سوء المعالجة أو طرق القيادة بخلاف تلك المحددة في دليل المستخدم أو خارج حدود السيارة (مثل الحد الأقصى للحمل والركاب وما إلى ذلك).

e) تلف السيارة الناجم عن استخدام عوامل تنظيف عدوانية أو رديئة على السيارة.

1. تسليم السيارة

1.1 فحص قبل تسليم السيارة

تم فحص السيارة الموضحة في الضمان المرفق بهذا الدليل قبل التسليم وفقًا للوائح شركة جي أيه سي للمركبات، يرجى طلب جدول فحص PDI من المتجر الخاص بالنسبة لعناصر الفحص المحددة.

تاريخ الفحص:

_____

موظف الفحص:

_____

ختم من المتجر الخاص

1.2 تسليم السيارة

ستقوم شركة جي أيه سي للسيارات بإجراء فحص شامل وتنظيف لسيارتكم الجديدة قبل التسلم، وستقدم قائمة الفحص قبل التسليم لكم للتأكيد والتوقيع.

إذا لم تكن راضيًا عن حالة سيارتكم عند التسليم، فيرجى إبلاغ المتجر الخاص بشركة جي إيه سي وتعديلها.

يرجى التأكد من التحقق مما إذا كانت هناك شهادة الضمان عند استلام السيارة، حيث لن تتمكن السيارة التي ليس لها شهادة ضمان من التمتع بخدمة الصيانة الأولي المجانية وتفقد الحق في الضمان.

قم بتسليم العناصر التالية مع السيارة (مثال☑ : نعم ☒ لا)	
☐ دليل المستخدم(رمز الاستجابة السريعة)	☐ الإطار الاحتياطي (اختياري)
☐ "دليل الضمان"	☐ مضخة النفخ + سائل إصلاح الاطارات (اختياري)
☐ "دليل القيادة"(رمز الاستجابة السريعة)	☐ مثلث التحذير
☐ "دليل الملاحة" (اختياري)	☐ السترة العاكسة
☐ شهادة مطابقة المنتج	☐ الأدوات التي يتم تسليمها مع السيارة (راجع دليل المستخدم)
☐ المفتاح الأول	☐ نموذج فحص الضمان قبل التسليم PDI المكتمل
☐ المفتاح الثاني	
تم تأكيد العناصر المذكورة أعلاه وتسليم السيارة المشتراة	
توقيع مالك السيارة/الشخص المخول:	
* إذا كانت سيارتكم مجهزة بالدليل المعني، يرجى ملاحظة ذلك التحقق	

بطاقة الضمان

معلومات المستخدم

اسم مالك السيارة:

سمات مالك السيارة: الصناعة:

رقم الهاتف:

عنوان تفصيلي:

الرمز البريدي:

تاريخ شراء السيارة: سنة شهر يوم

توقيع مالك السيارة:

سنة شهر يوم

معلومات السيارة

طراز السيارة:

رقم الإطار:

رقم المحرك:

تاريخ إصدار الرخصة:

اسم متجر الخاص للصيانة الأولى: اسم المتجر الخاص:

(ختم) (ختم)

سنة شهر يوم سنة شهر يوم

نسخة الضمان: نسخة المستخدم

فترة الضمان

تشير فترة الضمان إلى الفترة أو أميال السياق المحسوبة من تاريخ إصدار البائع لفاتورة الشراء.

فترة الضمان الأساسية لطراز EMPOW: 72 شهرًا أو 250,000 كيلومتر (أيهما يأتي أولاً).

فترة الضمان الأساسية للمركبة التجارية لطراز EMPOW: 12 شهرًا أو 100,000 كيلومتر (أيهما يأتي أولاً).

لوائح الضمان الأجزاء القابلة للاستهلاك وزيت التشحيم وسوائل العمل

- عندما الأجزاء القابلة للاستهلاك التالية هي الأجزاء التالفة الأولية ويكون سبب العطل ناتجًا عن عيوب في المواد أو تصنيعها، فإن إصلاح العطل يكون ضمن نطاق الضمان. والأجزاء القابلة للاستهلاك وفترة الضمان الخاصة بهم هي كما يلي:

الأجزاء القابلة للاستهلاك	فترة الضمان
عنصر فلتر الهواء، فلتر الزيت، فلتر الوقود، فلتر مكيف الهواء، المصباح الكهربائي، شمعة الإشعال، المصهر، الإطارات	3 أشهر أو 5000 كيلومتر، أيهما يأتي أولاً
حزام التدوير، لوحة احتكاك الفرامل، لوحة القابض، شفرة الماسحة، قرص الفرامل	6 أشهر أو 5000 كيلومتر، أيهما يأتي أولاً
وبطارية جهاز التحكم عن بعد	6 أشهر أو 10000 كم، أيهما يأتي أولاً
البطارية القابلة للشحن	12 شهرا أو 20000 كم، أيهما يأتي أولا

- زيت التشحيم، سائل العمل، إلخ. وزيت المحرك وزيت ناقل الحركة وزيت التروس التفاضلية وزيت تروس التوجيه وسائل التوجيه المعزز وسائل ناقل الحركة الأوتوماتيكي وسائل الفرامل وسائل القابض وسائل امتصاص الصدمات وسائل التنظيف والشحوم ومانع التجمد والمنحل بالكهرباء للبطارية والمبردات وغيرها من زيوت التشحيم وسوائل العمل لا يغطيها الضمان.
- بالإضافة إلى الوقود، عندما يجب استبدال الأجزاء والملحقات المذكورة أعلاه أو استكمالها بالضمان، يمكن تطبيق تكلفة الأجزاء والمواد على الضمان.

المحتوى

بطاقة الضمان 3

1. تسليم السيارة 4

1.1 فحص قبل تسليم السيارة 4

1.2 تسليم السيارة 4

2. تعليمات الضمان 5

2.1 تعليمات الضمان 5

2.2 مسؤولية مالك السيارة 7

2.3 واجب شركة جي أيه سي للسيارات 7

3. تعليمات العناية 8

3.1 جدول الصيانة الدورية 8

3.2 الصيانة التكميلية في ظروف السياق السيئة 11

3.3 جدول تسجيل الصيانة الدورية 13

4. تغيير المستخدم 16

مقدمة

مبروك على اختياركم جي أيه سي موتور وشكرا على ذلك!

نثق أن: سيارات جي إيه سي ستجلب لكم المزيد من متعة القيادة. من أجل الحفاظ على سيارتكم في حالة جيدة لفترة طويلة، يرجى الذهاب إلى المتجر الخاص بشركة جي إيه سي لإجراء الصيانة الدورية وفقًا لأحكام "جدول الصيانة الدورية" في هذا الدليل. ويمكن لالمتجر الخاص بشركة جي إيه سي تقديم خدمات عالية الجودة بأسعار معقولة. سيعمل الفنيون المدربون تدريبًا احترافيًا من قبل شركة جي أيه سي الدولية المحدودة (يشار إليها باسم شركة جي إيه سي) وفقًا لمواصفات تشغيل محددة.

يستخدم هذا الدليل كشهادة ضمان وصيانة سيارتك، يرجى ملء معلومات المستخدم بعناية والاحتفاظ بهذا الدليل بشكل صحيح، يجب تقديم هذا الدليل عند قبول الضمان وتقدم طلب في شركة جي أيه سي الدولية المحدودة.

أطيب التمنيات لكم: نأمل أن تجلب لكم سيارات جي إيه سي تجربة قيادة ممتعة!

شركة جي أيه سي الدولية المحدودة



GAC

EPSA202610

EMPOW

دليل الضمان